

DGS Workstation

SKU: DGS-WS8'L

Recommended Tools:

- Compact Drill/Driver
- T-25 Star Drive Bit
- Rubber Mallet
- Wood Glue



Part Number	Part Description	Quantity
CUSTOM	8' Workstation Side Rails	2
CUSTOM	32.5" Workstation Rungs	12
CUSTOM	Workstation Backer Boards	2
PTN3S5	3" Wood Screws	40

Need help?

Call 1-800-932-3339 or
 Email info@gymsupply.com

Step 1:

Lay out the **8' Workstation Side Rails** parallel to each other, leaving approximately 3ft of space between them. Place all **Workstation Rungs** between the side rails, aligning them with the corresponding holes.



IMPORTANT:

It is strongly advised to use **Wood Glue** for securing the **Rungs**. Apply a coat of **Wood Glue** inside the holes on the **Side Rails**. Press the **Rungs** firmly into place, using a **Rubber Mallet** if needed. Remove any excess glue that may have spilled out.


Step 2:

Rotate the **Rungs** until the pre-drilled holes in both the **Side Rails** and **Rungs** align. Utilize a **Compact Drill/Driver** along with **3" Wood Screws** to securely attach the **Rungs** to the **Side Rails**.



Step 3:

Once all the **Rungs** have been positioned, proceed to install the **Backer Boards**. Ensure that the top **Backer Board** is oriented in a way that the logo is facing the front of the Workstation. Fasten it to the back of the **Side Rails** using **3" Wood Screws** at the specified locations with cutouts. Repeat the same process for the bottom **Backer Board**.



Step 4:

Your DGS Workstation is now prepared for wall mounting. Consider the type of wall you are using for installation and secure it with the appropriate anchors. Attach the Workstation to the wall by using **3" Wood Screws** through the **Backer Boards**.